

**BT 5 AM**  
**Operator Panel**  
**for Stepper Motor Control Units**  
**OMC and TMC,**  
**MCC-1 and MCC-2**  
  
**User Manual**

**TRANSLATION OF THE GERMAN ORIGINAL MANUAL**

---

All rights with:

Phytron GmbH

Industriestraße 12

82194 Gröbenzell, Germany

Tel.: +49(0)8142/503-0

Fax: +49(0)8142/503-190

Every possible care has been taken to ensure the accuracy of this technical manual. All information contained in this manual is correct to the best of our knowledge and belief but cannot be guaranteed. Furthermore we reserve the right to make improvements and enhancements to the manual and / or the devices described herein without prior notification.

We appreciate suggestions and criticisms for further improvement. Please send your comments to the following  
E-mail address: [doku@phytron.de](mailto:doku@phytron.de)



## Contents

1	Legal Instructions .....	4
2	Safety Instructions .....	5
3	The BT 5 AM Operator Panel .....	6
4	Control Elements .....	7
4.1	Editing Keys .....	7
4.2	Control Keys .....	8
4.3	Function Keys .....	10
5	Panel Settings .....	11
6	Connecting the Control Unit .....	12
7	Communication with the Control Unit .....	13
7.1	F1: Manual mode .....	14
7.2	F2: Diagnosis / Status .....	16
7.2.1	Submenu F1: Output Status .....	16
7.2.2	Submenu F2: Input Status .....	17
7.2.3	Submenu F3: Limit Switch Status (Initiator Status) .....	18
7.2.4	Submenu F4: Power Stage Diagnosis .....	18
7.2.5	Submenu F5: Display Version .....	19
7.2.6	Submenu F6: Reset Controller .....	19
7.3	F3: Auto Boot .....	20
7.4	F4: Without Function .....	20
7.5	F5: Registers .....	20
7.6	F6: Parameters .....	22
8	Montage .....	23
9	Technical Data .....	24

1 Legal Instructions

**i** **This manual:**  
*Read this manual very carefully before mounting, installing and operating the device and if necessary further manuals related to this manual.*

- Please pay special attention to instructions that are marked as follows:

	<b>DANGER – Serious injury!</b>	<i>Indicates a high risk of serious injury or death!</i>
	<b>DANGER – Serious injury from electric shock!</b>	<i>Indicates a high risk of serious injury or death from electric shock!</i>
	<b>WARNING – Serious injury possible!</b>	<i>Indicates a possible risk of serious injury or death!</i>
	<b>WARNING – Serious injury from electric shock!</b>	<i>Indicates a possible risk of serious injury or death from electric shock!</i>
	<b>CAUTION – Possible injury!</b>	<i>Indicates a possible risk of personal injury.</i>
	<b>CAUTION – Possible damage!</b>	<i>Indicates a possible risk of damage to equipment.</i>
	<b>CAUTION – Possible damage due to ESD!</b>	<i>Refers to a possible risk of equipment damage from electrostatic discharge.</i>
	<b>”Any heading“</b>	<i>Refers to an important paragraph in the manual.</i>

## 2 Safety Instructions

---



The fuse may only be changed by qualified and trained personnel!

In electrical systems dangerous voltages may exist.

When touching powered components there is the **danger of electric shock!**



Electrostatic discharging can destroy electronic components! ESD protective measures should be respected!

## 3 The BT 5 AM Operator Panel

---



Fig.1 BT 5 AM Operator panel

Type BT 5 AM operator panels may be connected to the service port connector of OMC or TMC stepper motor control units or to the X5 Com interface of the MCC controller.

During production, the operator can do some entries enabled for change: e.g. select other machine programs, adjust throughput, change quantities etc.

If required, the operator panel displays text lines or error messages. Function keys can be individually labelled.



In the Remote/Terminal mode you can enter motion commands, set outputs or display status messages.

With multi-axis systems, the operator panel should be connected to the master OMC or TMC. All slaves connected can be operated and monitored with only one operator panel.

## 4 Control Elements







### 4.1 Editing Keys

<p>( ) ° 0</p>	<p>The key <b>0 and ( )°</b> is used for changing data in the editor. The (, ) and ° characters can be entered when configuring the <b>Shift</b> or <b>ShiftCase</b> system variables.</p>
<p>STU 1</p>	<p>The key <b>1 and STU</b> is used for changing data in the editor. The S, T and U characters can be entered when configuring the <b>Shift</b> or <b>ShiftCase</b> system variables.</p>
<p>VWX 2</p>	<p>The key <b>2 and VWX</b> is used for changing data in the editor. The V, W and Y characters can be entered when configuring the <b>Shift</b> or <b>ShiftCase</b> system variables.</p>
<p>YZ% 3</p>	<p>The key <b>3 and YZ%</b> is used for changing data in the editor. The Y, Z and % characters can be entered when configuring the <b>Shift</b> or <b>ShiftCase</b> system variables.</p>
<p>JKL 4</p>	<p>The key <b>4 and JKL</b> is used for changing data in the editor. The J, K and L characters can be entered when configuring the <b>Shift</b> or <b>ShiftCase</b> system variables.</p>
<p>MNO 5</p>	<p>The key <b>5 and MNO</b> is used for changing data in the editor. The M, N and O characters can be entered when configuring the <b>Shift</b> or <b>ShiftCase</b> system variables.</p>
<p>PQR 6</p>	<p>The key <b>6 and PQR</b> is used for changing data in the editor. The P, Q and R characters can be entered when configuring the <b>Shift</b> or <b>ShiftCase</b> system variables.</p>
<p>ABC 7</p>	<p>The key <b>7 and ABC</b> is used for changing data in the editor. The A, B and C characters can be entered when configuring the <b>Shift</b> or <b>ShiftCase</b> system variables.</p>
<p>DEF 8</p>	<p>The key <b>8 and DEF</b> is used for changing data in the editor. The D, E and F characters can be entered when configuring the <b>Shift</b> or <b>ShiftCase</b> system variables.</p>
<p>GHI 9</p>	<p>The key <b>9 and GHI</b> is used for changing data in the editor. The G, H and I characters can be entered when configuring the <b>Shift</b> or <b>ShiftCase</b> system variables.</p>
<p>:?! .</p>	<p>The key <b>Decimal point and :?!</b> is used for changing data in the editor. The characters :, ? and ! can be entered when configuring the <b>Shift</b> or <b>ShiftCase</b> system variables.</p>






	The <b>key Plus and &lt;=&gt;</b> is used for changing data in the editor. The characters <, = and > can be entered when configuring the <b>Shift</b> or <b>ShiftCase</b> system variables.
	The key <b>Minus and \*/</b> is used for changing data in the editor. The characters \, * and / can be entered when configuring the <b>Shift</b> or <b>ShiftCase</b> system variables.

### 4.2 Control Keys

---

	<b>Cursor left</b> In the editor, it moves the cursor one character to the left (character selection). This function corresponds to the system variable <b>KeyCursLeft</b> .
	<b>Cursor right</b> In the editor, it moves the cursor one character to the right (character selection). This function corresponds to the system variable <b>KeyCursRight</b> .
	<b>Cursor down</b> In the editor, it moves the cursor down one variable (variable selection). This function corresponds to the system variable <b>KeyCursDown</b> .
	<b>Cursor up</b> In the editor, it moves the cursor up one variable (variable selection). This function corresponds to the system variable <b>KeyCursUp</b> .
	<b>Cursor home</b> In the editor it returns the cursor to the first input variable position. This function corresponds to the system variable <b>KeyHome</b> .
	<b>Page down</b> This function corresponds to the system variable <b>TabPgDn</b> .









	<p>The question mark key is not assigned.</p>
	<p>The key <b>Data Release</b> changes from the menu into the editor. The integrated LED is lit during edit mode. Pressing this key in edit mode exits the editor.</p>
	<p>The key <b>Enter</b> is used to complete data entry. Pressing this key while the start up screen is displayed opens the setup screen.</p>
	<p>The key <b>Delete</b> deletes the character beneath the cursor in the editor.</p>
	<p>The <b>Print</b> key is not assigned.</p>


### 4.3 Function Keys

---

The operator panel has six function keys F1 to F6. When pressing a function key the mode described below will be active. Now you can do several inquiries or inputs described in the following chapters.

	Manual mode
	Diagnosis / Status
	Auto boot
	Not used
	Registers
	Parameters

## 5 Panel Settings



- 1 Female connector X5 (Ethernet)
- 2 Female connector X6 (Serial interface)
- 3 Female connectors X9, X10 (USB Host - type A)
- 4 Threaded bolt for protective grounding
- 5 Termination switch (RS422/RS485)
- 6 Connector X1 (Supply voltage)

Fig.2 Interfaces

6 Connecting the Control Unit




Fig.3 Cable operator panel – OMC/TMC control unit





Fig.4 Cable operator panel – MCC control unit

<p><b>i</b></p>	<p><b>Termination switch</b></p>	<p><i>During operation of the interface as RS232 the termination switch should be switched to ,OFF' (fig.2).</i></p>
-----------------	----------------------------------	--

## 7 Communication with the Control Unit

As soon as control unit and operator panel are connected (see chapter above) you can switch on the power supplies of all units.

	<b>READY</b>	<p><i>The operator panel is ready after 25 sec power on. The baud rate is set to 38400 baud.</i></p>
---	--------------	--

Dependent on the controller's operating mode (Remote/Local switch), one of the following messages will be shown on the operator panel's display:

Position of Remote/Local Switch (OMC/TMC)	Display (terminal)	
Remote	Remote / Terminal	Function keys F1 to F6 are active.
Local	Local	The displayed text can be generated by a MINILOG program (see MINILOG programming manual).

If there is no communication with the control unit, please check the cabling.

## 7.1 F1: Manual mode

---

After pressing **F1** the display shows 'Manual Mode'. In this mode, several functions are available:

### Reference run



Press key 0.

Now you will be asked to select an axis for reference run.

Display: **Axis ?**

Input: Digits 1 to 8




Press the ENTER key. Reference run will be started.

Abort reference run: Press any key.

### Manual mode

With the numerical keys the motors (here: axes 1 and 2) can be driven according to the scheme below:



### Change axes:

With the arrow keys



and



you can change to two other axes. Always the next two axes can be selected.

At systems with an odd number of axes, finally only one axis will be displayed, e.g. at 3 axes the 3rd axis.

+ = plus direction

- = minus direction







The direction of rotation depends on the stepper motor wiring. To change the direction of rotation, you only have to change the leads of one motor phase (e.g. A and B).



## 7.2 F2: Diagnosis / Status

---

As soon as this mode is active, several submenus can be selected with the function keys:

	Inquire and change output status
	Inquire input status
	Inquire limit switch status
	Power stage diagnosis
	Display version
	Reset control unit

### 7.2.1 Submenu F1: Output Status

---

Select the submenu 'output status' with key **F1** from the menu 'diagnosis/status'. Now the output status can be inquired or changed.

The outputs are displayed in groups of eight: **0000 0001**

In this example: The outputs 1 to 7 are off. Output 8 is set.




With the arrow keys and the SCROLL key you can display all outputs one group after another.

For changing the output status the input mode has to be enabled:









Press the INPUT key

The green LED on the input key shines. In the display the cursor blinks at the first sign of the selected group of outputs.

	Move the cursor to the output which has to be changed (input mode)
	
	Move the cursor to the previous group of outputs







 	Move the cursor to the next group of outputs
 	Change output status (input mode): 0 = off 1 = output set
	Leave the input mode and transmit the actual state to the controller
	Leave the mode 'output status' without storing the changes

### 7.2.2 Submenu F2: Input Status

From the menu 'Diagnosis/Status' you can select the submenu 'Input Status' with the key **F2**. The states of all available inputs are displayed in groups of 16 (OMC/TMC) or in groups of 8 (MCC) for example: **0000 0000 0000 0001, 0000 0001**

In example OMC/TMC the inputs 1 to 15 are off, input 16 is on, in example MCC the inputs 1 to 7 are off, input 8 is on.

 	Scroll from input group to the next or previous input group.
	Change to the next input group
	Leave the mode 'Input Status'

### 7.2.3 Submenu F3: Limit Switch Status (Initiator Status)

---

From the menu F2 'Diagnosis/Status' you can select the submenu 'Limit switch status' with the key **F3**. The states of all available limit switches (initiators) are displayed.

**I = 0** Limit switch is supplied with 24 V, but not damped (free)


**I = +** Limit switch + direction is damped

**I = -** Limit switch - direction is damped

**I = 2** no limit switch connected or both limit switches are damped

Example: **I = 02+-**

The system has 4 axes, limit switch of axis 1 is free, for axis 2 no limit switch is connected, the limit switch of the direction + of axis 3 is damped, and the direction - limit switch of axis 4 is damped, too.

	Leave the limit switch status mode
---	------------------------------------

### 7.2.4 Submenu F4: Power Stage Diagnosis

---

From the menu F2 'Diagnosis/Status' you can select the submenu 'Power stage diagnosis' with the key **F4**. The states of all available power stages are displayed as follows:


**No. of power stage = status code number**

The power stages are numbered serially: **1, 2, 3** etc

Power stage status code number	Meaning
<b>1</b>	Over current error
<b>2</b>	Under voltage error
<b>4</b>	Over temperature error
<b>7</b>	No power stage
<b>8</b>	Power stage is activated
<b>0</b>	Power stage is not activated

Example: 1 = 4 2 = 4 3 = 7

In this example, over temperature is displayed for power stages 1 and 3. The power stage of axis 3 is not connected or not recognized.

	Leave the mode power stage status
---	-----------------------------------


## 7.2.5 Submenu F5: Display Version

From the menu F2 'Diagnosis/Status' you can select the submenu 'Display version' with the key **F4**. Now the program version numbers of the controller are displayed:

**BIOS = version no.**



**SYS = version no.**

**Indexer = version no. (MCC)**

	Leave the mode display version
---	--------------------------------

## 7.2.6 Submenu F6: Reset Controller

From the menu F2 'Diagnosis/Status' you can select the submenu 'Reset controller' with the key **F6**. Now the following inputs are valid:

	Key ENTER: Resets the controller
	Key CLEAR: Leave the mode 'Reset controller' without reset.

### 7.3 F3: Auto Boot

---

After you press the **F3** key the display shows the register for the program which is set at auto boot. In addition, another register can be selected as an auto boot program.

### 7.4 F4: Without Function

---

In the actual program version this key is without function.

### 7.5 F5: Registers

---

After pressing **F5** the display shows a register list. In this mode several functions are available:










With the arrow keys and the SCROLL key you can display all available registers.





For changing the register values the input mode has to be enabled:



Press the INPUT key

The green LED on the input key shines. In the display the cursor blinks on the first sign of the register value. With the numeral keys register values can be entered or edited.

 	Scroll from register to register
 	Scroll groups of ten registers up and down
	Scroll up groups of ten registers
 	Scroll up groups of hundred registers
	Enable the register edit input mode, the cursor is displayed under the first digit of the value.
	Set register to <b>0</b> (input mode)

 	Move the cursor (input mode)
	Confirm register value (input mode)
	Leave the 'Register' mode

## 7.6 F6: Parameters

---

After pressing **F6** the display shows a list of controller specific parameters. There is a separate list for each axis.











First parameter 1 of the first axis is displayed. With the arrow keys you can scroll the parameter list.

For changing the parameter values you have to enable the input mode:



Press the INPUT key

The green LED on the input key shines. At the display the cursor blinks on the first digit of the parameter value. With the numeral keys parameter values can be entered or edited..

 	Scroll through the parameter list of an axis
 	Change to the parameter list of the next or the previous axis
	Enable the input mode for editing parameter values. The cursor is at the first digit of the value.
	Parameter is set to <b>0</b> (input mode)
 	Move the cursor (input mode)
	Confirm the parameter value (input mode)
	Leave the 'Parameter' mode

## 8 Montage

By means of the attached holding clamps the terminal can be integrated into switching tables or else with 1 to 14 mm thickness. Mounting material and a sealing frame are delivered with the device.

The terminal has to be inserted into the mounting cut-out and fastened to the mounting wall from the rear side with the holding clamps. Hang up the holding clamps into both slots at the sides of the terminal. Arrest them with the setscrews at the mounting wall.

Around the terminal a free space of at least 30 mm is required to ensure sufficient air circulation.

Front panel dimensions (H x W x D)	168 x 120 x 4 mm
Mounting cut-out (H x W)	160 x 112 mm (+1 mm, – 0 mm)
Mounting depth	46 mm




Fig.5 Mounting cut-out

## 9 Technical Data

<b>Keyboard</b>	
<b>Type</b>	Membrane keyboard
<b>Number of keys</b>	30
<b>Key area (raised)</b>	11 mm (H x B)
<b>Actuator travel</b>	0.3 mm
<b>Actuating force</b>	3 N
<b>Switch cycles</b>	Approx. 3 million under the following conditions: Pressing element: test plunger (DIN 42115) Pressing force: 10 N Pressing frequency: 1 Hz
<b>Lifetime (min.)</b>	2 million switch cycles
<b>Display elements (status LEDs)</b>	9
<b>Display</b>	
<b>Type</b>	FSTN (mono)
<b>Resolution (pixels)</b>	160 x 80
<b>Colours</b>	5 Shades of gray
<b>Reading angle</b>	80°
<b>Contrast setting</b>	Temperature compensated
<b>Half-life backlighting</b>	50.000 h
<b>Brightness in cd/m<sup>2</sup></b>	45
<b>Display area (H x W) in mm (Inch)</b>	33.6 x 67.2



<b>Electrical Data</b>	
<b>Supply voltage</b>	24 V DC (SELV / PELV in accordance with DIN EN 61131)
<b>Residual ripple</b>	10% maximum
<b>Minimum voltage</b>	18 V
<b>Maximum voltage</b>	30 V
<b>Power consumption (typical at 24V)</b>	0.25 A
<b>Power consumption (maximum)</b>	0.35 A
<b>Connected load</b>	6 W
<b>Fuse</b>	Semiconductor fuse, self-resetting
<b>Protection against polarity reversal</b>	Integrated
<b>Serial Interface</b>	
Baud rate: 38400	
<b>X2 RS232</b>	In accordance with DIN 66259 T1, CCITT V.28 Transmission length: 0 - 15 m, conductors layered in strands, shielded, electrically isolated
<b>Central Processing Unit</b>	
<b>Central processing unit</b>	RISC ARM9
<b>Clock frequency</b>	200 MHz
<b>Other features</b>	Watchdog timer, real-time clock, battery monitoring

<b>Memory</b>	
<b>Application memory (option)</b>	3 MByte (14 MByte)
<b>Flash (option)</b>	16 MByte (32 MByte)
<b>SDRAM (option)</b>	32 MByte (64 MByte)
<b>SRAM (option)</b>	512 KByte (512 KByte)
<b>Connection System</b>	
D-SUB female and male connector strips, 9 pin and 25 pin	
Female and male connector strips, Phoenix COMBICON / MINI COMBICON, 3 pin	
Male connector strip, Phoenix COMBICON, 5 pin	
RJ45 female connector	
USB female connector A	
<b>Environmental Conditions</b>	
<b>Temperature during operation</b>	0°C to 50°C
<b>Temperature during storage, transport</b>	-25°C to +70°C
<b>Relative air humidity for operation and storage</b>	20% to 85%, no condensation
<b>Application area</b>	Degree of pollution 2, overvoltage category III

<b>Standards and Guidelines</b>	
<b>Interference immunity</b>	DIN EN 61000-4-2 DIN EN 61000-4-3 DIN EN 61000-4-4 DIN EN 61000-4-5 DIN EN 61000-4-6 DIN EN 61000-6-2
<b>Emitted interference</b>	DIN EN 55011 limit value class A DIN EN 55022 limit value class A DIN EN 61000-6-4
<b>Equipment requirements</b>	DIN EN 61131-2
<b>Storage and transportation</b>	DIN EN 61131-2
<b>Power supply</b>	DIN EN 61131-2
<b>Electromagnetic compatibility</b>	2004/108/EG
<b>Degrees of protection</b>	DIN EN 60529
<b>Impact load, shocks</b>	DIN EN 60068-2-27
<b>Sinusoidal vibrations</b>	DIN EN 60068-2-6
<b>Approvals</b>	
CE, UL, cUL	

Front Panel and Enclosure	
<b>Enclosure</b>	Steel sheet, galvanised
<b>Front panel material</b>	Aluminium, brushed, anodized natural finish
<b>Front panel (HxWxD) in mm (Inch)</b>	168 x 120 x 5 (6.614 x 8.333 x 0.197)
<b>Front panel cover</b>	Polyester foil
<b>Seal</b>	Circumferential rubber seal on the rear
<b>Mounting cutout (HxW) in mm (Inch)</b>	160 x 112 (6.299 x 4.409)
<b>Mounting depth</b>	About 43 mm (1.693") Standard / field bus device: about 55 mm (2.165")
<b>Degree of protection</b>	Front: IP65 Rear: IP20
<b>Total weight</b>	About 500 g







